


MEET YOUR FIRE MAX 11



ACTIVATE YOUR FIRE MAX 11



TROUBLESHOOTING

For troubleshooting tips and Amazon Customer Service, visit www.amazon.com/devicesupport.



USE WITH ACCESSORIES

All accessories sold separately, including Fire Max 11 Keyboard Case, Made for Amazon Stylus Pen and microSD card.

ATTACH KEYBOARD CASE



Attach the keyboard case to make it easier to type, navigate and do more on your Fire Max 11.

ATTACH THE PEN



EXPAND STORAGE



CONNECT HEADPHONES

